
AERATRON

Ceiling Extension Instruction




IMPORTANT - Use this Ceiling Extension Instruction in combination with the Aeratron User Manual by Inserting after **STEP 2** of the User Manual supplied with the Fan.

Unpack your EXTENSION KIT and examine all parts, you should have the following:




PLEASE NOTE: A small colour variation between the Fan and the retrofit Extension Parts is part of standard manufacturing tolerances and consequently will need to be accepted by the user.


STEP 1 Remove Suspension Ball



Remove Suspension Ball Screw




Push Suspension Ball down





Remove suspension Bolt and Suspension Ball from Motor Shaft

STEP 2 Fit Extension Bracket and Rod




STEP 3 Assemble Extension parts to Extension Rod






Insert the Suspension Bolt.





Raise the Suspension Ball to cover the Suspension Bolt and tighten the Suspension Ball Screw.

STEP 4 Fix Canopy Screw to Hanger Bracket




Fix one Canopy Screw to Hanger Bracket.






Leave a 2mm gap to the Hanger Bracket


STEP 5 Position the Motor Assembly in Hanger Bracket



STEP 6 Attach Canopy and Decoration Ring




- Push Canopy up and rotate clockwise on existing Canopy Screw.
- 2 Insert second Canopy Screw & tighten both.



3 Line up large holes in Decoration ring with screw heads, push up and rotate counter clockwise.

Note: Move / swivel the motor assembly sideways for easy canopy screw access.

STEP 7 Install Receiver into Extension Bracket





IMPORTANT - Continue at **STEP 5** (Connecting the Reciever) of the User Manual supplied with the fan to complete the installation.

For General Information & Warranty issues refer to the Aeratron™ User Manual available at www.aeratron.io

Thank you. Your Aeratron team.

AERATRON

Ceiling Extension Edition 2021/06